



RTC Manufacturing, Inc.

P. O. Box 150189
Arlington, TX 76015

(800) 782-8721
(817) 274-3610 fax

Model TR-3 / TR-4
GPS Time Reference

Application Note Number 15

Setup Instructions for the TR-3 / TR-4 GPS Time Reference
for

2070 / SEPAC

Connect the TR-3 relay common wire to pin 14 (logic ground) and the normally open wire to pin 27 (time set) on the "C11" connector which is the Time Set function.

Set the switches on the TR-3 / TR-4 for a time reset at 4:00AM, Everyday (EDY) per the TR-3 / TR-4 programming instructions.

NOTE: RTC can supply the C11 connector with the harness when you purchase a TR-3 / TR-4 for use with a 2070 controller running the SEPAC software. Notify your RTC dealer or RTC directly if you would like this option.

DISCLAIMER:

The information contained in this application note is accurate to the best of our knowledge. It is the responsibility of the end user to determine the method of resetting the time of day on the exact model and firmware version of the controller being used.